

IMPORTANT SAFETY INSTRUCTIONS

READ AND SAVE THESE SAFETY INSTRUCTIONS BEFORE
USING THIS PRODUCT.

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:


1. Use only as described in this instruction manual.
2. This product operates at 120V, 60 Hz only.
3. Do not use this product if it is damaged in any way or form. Immediately unplug the unit and return it for service under the warranty agreement for repair.
4. To reduce the risk of electric shock, this equipment has a grounding type plug that has a third earth pin. This plug will only fit into a 3-pin type power outlet. If the plug does not fit to the outlet, contact qualified personnel to install the proper outlet. Do not alter the plug in any way.
5. Do not operate this product with a damaged cord or plug or if the product malfunctions or has been dropped or damaged in any manner. Return this product to an authorized service facility for examination, electrical or mechanical adjustment, or repair.
6. For indoor use only. This product is not intended for use in bathroom, laundry areas or similar moist indoor locations. Never locate this product where it may fall into a bathtub or other water container.
7. Always unplug this product when not in use or prior to cleaning.
8. Close attention is necessary when this appliance is operated near children. This is not a toy.

9. Do not pull, lift or carry by the power cord. Do not use the cord as a handle, close a door on the cord, or pull the cord around or against sharp edges or corners.
10. Do not place this product near any heat sources such as stoves, radiators, and heaters.
11. There are no user-serviceable parts inside this product. Any attempt to open and service this unit will void the warranty and could lead to serious damage to the unit/or personal injury.
12. Turn the unit off before unplugging from an electrical outlet. Grip the plug and pull it from the wall outlet. Never pull by the cord.
13. Do not handle the product or the plug with wet hands.
14. Do not put any objects through any grilles or other openings in the product. Keep all openings free of dust, lint, hair, or other materials which may reduce airflow.
15. Keep hair, fingers or loose clothing away from grilles or other openings of the product.
16. Do not operate the unit in areas where flammable or combustible products or vapors may be present.
17. Do not operate this product in oxygen rich environments.
18. The collection rod has many edges and areas that can trap water. The collection rod should be completely dry before installing it into the unit.

19. READ AND SAVE THESE INSTRUCTIONS.

NOTE:

The ionizing process used by the IONICA Electrostatic ionic tower with ozonizer produces small amounts of ozone as a by-product. This unit complies with U.S. Government limits for acceptable levels of ozone (less than 50 parts per billion by volume of air circulating through the product). People with a history respiratory problems or lung disease should consult a physician before using this product.



SET-UP:

- Select a firm level and flat location. For proper air flow, locate the unit at least 3 feet(1 M) from any wall or furniture.
- Ensure the exit grille faces away from the nearest wall or furniture.
- Ensure no grilles are blocked.
- Plug into a grounded 120V/60 Hz outlet. See IMPORTANT SAFETY INSTRUCTIONS.
- Do not lift the unit by the Top Cover.

OPERATION: POWER LEVEL

- Ensure the collector Rod is firmly seated in place and the top cover is securely latched.
- Turn the selector switch to Low or High, then switch on the power.
- The indicator light will illuminate automatically.
- To switch off, turn the selector switch to off position, then off the power.

REMOVING/INSTALLING THE COLLECTOR ROD:

● **To remove the Collector Rod:**

1. Unplug the Electrostatic ionic tower with ozonizer.
2. Press the Control Panel Release Button and flip the top cover backward.
3. Grip the Collector Rod handle and pull-up firmly.

● **To install the Collector Rod:**

1. Ensure the Electrostatic ionic tower with ozonizer is unplugged.
2. The Collector Rod inserts only one way. Align the Collector with the opening in the Electrostatic ionic tower with ozonizer.
3. Press down until the Collector Rod seats firmly in place. Ensure the top handle is flush with the surrounding surface.
4. Flip the cover forward and securely latch in place.

CLEANING THE COLLECTOR ROD:

For common household particles:

- Remove the Collector Rod as described above.
- Use a soft, damp cloth to wipe the surface of the Collector Rod.
- Ensure that the Collector Rod is completely dry.
- Insert the Collector Rod back into the unit.
- Clean the Collector Rod every 2-3 weeks, sooner if needed.

For tobacco smoke or particles that are not easily removed:

- Remove the Collector Rod as described above.
- Use a scrub sponge coated with a mild soap and water solution and wipe the Collector Rod from top to bottom.
- Wipe down the Collector Rod with a damp cloth and ensure that no soap residue remains on the Collector Rod and it is completely dry.(Do not place under running water to rinse.).
- Insert the Collector Rod back into the unit.
- Clean the Collector Rod every week, sooner if needed.

Your Electrostatic ionic tower with ozonizer may experience some discoloration on the Collector Rod over time. This is normal and does not affect the performance of the product in any way.


CLEANING AND MAINTENANCE:

The Electrostatic ionizer/ozonizer should be cleaned at least once every three weeks. More frequent cleaning may be required depending upon environmental conditions.

- Turn-off and unplug the Electrostatic ionizer/ozonizer.
- Press the control panel release button and rotate the panel up.
- Remove and clean the Collector Rod as previously described.
- Turn the unit upside-down 2 or 3 times and hold for at least 3 seconds each time. This allows the cleaning bars inside the unit to scrape any accumulated debris off the electronic wires.

Note: Do not stick any foreign objects or your fingers inside the unit.

- Use a clean, dry cloth to wipe the external surface of the Electrostatic ionizer/ozonizer. **DO NOT USE WATER, GASOLINE, POLISH OR ANY CHEMICAL SOLUTION.**



TROUBLESHOOTING:

If your air cleaner shuts off unexpectedly, safety features may have been activated to prevent damage or injury. If this happens:

- Be sure the Electrostatic ionizer/ozonizer is plugged into a working electrical outlet.
- Check to be sure the Collector Rod is firmly seated in place.
- Check to be sure the top cover is latched firmly in place.

NOTE:IF YOU CONTINUE TO EXPERIENCE A PROBLEM, PLEASE RETURN THE ELECTROSTATIC IONIZER/OZONIZER TO THE PLACE OF ORIGINAL PURCHASE OR SEE YOUR WARRANTY. DO NOT ATTEMPT TO OPEN THE ELECTROSTATIC IONIZER/OZONIZER YOURSELF. DOING SO MAY VOID YOUR WARRANTY AND CAUSE DAMAGE TO THE PRODUCT OR PERSONAL INJURY. IF YOU HAVE ANY QUESTIONS REGARDING THE ELECTROSTATIC IONIZER/OZONIZER,PLEASE CALL OR WRITE:

FREQUENTLY ASKED QUESTIONS:

- How often is cleaning required?
 - About every three weeks depending upon your atmospheric conditions.
- Is the Electrostatic ionic tower with ozonizer considered an ozone generator?
 - No. Ozone generators produce large amounts of ozone and the EPA considers these unsafe for household use. The Electrostatic ionic tower with ozonizer electrostatically removes particles from the air and release only trace amounts of ozone.
- Why does the fan speed or sound do not change when I change the power settings?
 - Changing the power setting only changes the voltage(cleaning power) of the electrostatic wires inside the unit. The fan speed is constant no matter what power setting is used.

- My Electrostatic ionic tower with ozonizer was making a “cracking” sound and now it doesn’t seem to be cleaning the air any more. Is it broken?
-No. The Electrostatic ionic tower with ozonizer needs to be cleaned. When too much dirt accumulates on both the collector and electrostatic wire, the power to the Collector and Rod turns-off, but the fan will continue to run. Clean the unit and it should then operate normally. See CLEANING THE COLLECTOR ROD and CLEANING AND MAINTENANCE.

ELECTRICAL SPECIFICATIONS:

120V, 60 Hz, 8 watts

Ozone output: 15mg/hour

1 YEAR LIMITED WARRANTY

You should first read all instructions before attempting to use this product.

- A. This 1 year limited warranty applies to repair or replacement of product found to be defective in material or workmanship. This warranty does not apply to damage resulting from commercial, abusive, unreasonable use or supplemental damage. Defects that are the result of normal wear and tear will not be considered manufacturing defects under this warranty.
- We ARE NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE DURATION OF THIS WARRANTY.

Some jurisdictions do not allow the exclusion, or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitation or exclusions may apply to you. This warranty gives you specific legal rights, and you also may have other rights which vary from jurisdiction to jurisdiction. This warranty applies only to original purchaser of this product from the original date of purchase.

- B. At its option, we will repair or replace this product if it is found to be defective in material or workmanship. Defective product should be returned to the place of purchase in accordance with the store policy. Thereafter, while within the warranty period defective product may be returned to us.
- C.
 1. This warranty does not cover damages resulting from any unauthorized attempts to repair or from any use not in accordance with the instruction manual.
 2. If you have any questions or comments regarding this unit, please write to our Customer Service Department at ionica_air_enhancer@hotmail.com.
 3. If a product does not operate as warranted during the applicable warranty period, please send to the dealer.
 4. All shipping charges must be prepaid by you.
 5. **IMPORTANT RETURN INSTRUCTIONS:** Your warranty depends on your following these instructions if you are returning the unit.
 - A) Carefully pack the item in its original carton or other suitable box to avoid damage in shipping.
 - B) Before packing your unit for return, be sure to enclose:
 - a) Your name, full address with zip/postal code and telephone number,
 - b) A dated sales receipt or **PROOF OF PURCHASE**,
 - c) Your \$15.00 (USD) check for return shipping and handling, and
 - d) The model number of the unit and the problem you are having. - Enclose in an envelope and tape directly to the unit before the box is sealed.
 - e) You must ship the package insured.
 6. This warranty does not cover the product if it is damaged by accident and/or improper use.
 - 7.

This Warranty applies ONLY to repair or replacement of any supplied or manufactured parts of this product that, upon inspection by the agent, authorized personnel, is shown to have failed in normal use due to defects in material or workmanship.

8. Operating this unit under conditions other than those recommended or at volatages other than the voltage indicated on the unit, or attempting to service or modify the unit, will render this WARRANTY VOID.